

## **EV-MASS ENCLOSED BUCHNER FUNNEL**

### **CLOSED-LOOP VACUUM FILTRATION**

Adaptability is a vital factor in any emerging industry. And cannabis is no different. As extracts become a more prominent and profitable opportunity, producers need the ability to continually iterate upon their manufacturing process to achieve new target objectives.

Our EV-MASS Enclosed Buchner Funnel meets the growing demands of the cannabis market. Its closed-loop, sanitary design will accommodate your budget, while meeting the requirements of GMP.

**BOOK A CONSULTATION WITH  
AN EVOLVED EXTRACTION  
SPECIALIST TODAY.**

### **A NATURAL SELECTION**

- Small footprint
- Designed for easy clean-ability
- Filter up to 10L / min GMP Compliant
- Pair with legacy CO2 systems for greater production output
- Rated for C1D1/C1D2 locations
- Guaranteed performance on a 12-month warranty
- Receive leading after-sale support & supply of parts & solvents

**CLOSED-LOOP HIGH-  
EFFICIENCY FILTRATION**

**EVOLVEXTRACTION.COM**



**COMPACT FOOTPRINT.  
REDUCED LABOUR.  
INCREASED OUTPUT.**

We designed the EV-MASS Enclosed Buchner Funnel to better synchronize and streamline the the filtration process without compromising quality. The result? We've optimized your efficiency, reduced your labour and increased your output in the winterization and filtration of micella - All while meeting the rigorous standards of GMP compliance.

**CLOSED-LOOP FILTRATION AT THE FLIP OF A SWITCH.**

Large filtration surface area and easy clean-ability are two examples of how the EV-MASS Enclosed Buchner can improve your facility's processing efficiency.

Your option of 58L (15.5 gal) stainless steel kegs or 10L (2.6gal) vacuum rated glass bottles ensure no pouring is required, freeing up labour and avoiding costly spills. Pre-cut nylon filter papers are available in 10, 5, and 1 micron to perform effective removal of fats, waxes and lipids from any form of extract. Equipment rated for solvents like ethanol, isopropyl, pentane and hexane.



**"FILTRATION IS IN OUR DNA"**

**SYSTEM AGNOSTIC AUXILIARY SKIDS  
FILTRATION SOLUTIONS FOR CO<sub>2</sub>, ETHANOL &  
HYDROCARBON SYSTEMS**

- Removes suspended lipids, fats, & waxes from winterized micella
- Multiple micron filters available in 25, 10, 5, & 1
- Made in Canada quality & reliability
- Filters up to 10L (2.6 gal) per minute

“

**IT'S ALL ABOUT NO  
MORE POURING!  
100% VACUUM  
OPERATED - YOU  
CAN SET IT &  
FORGET IT**

**-Adam Temple, Evolved  
Extraction**